


- Explosionszeichnung -

RP-32/RP-32-1/RP-32H/RP-32-1H PARTS AND EXPLODED DIAGRAM



PARTS NO.	DESCRIPTION	QTY	PARTS NO.	DESCRIPTION	QTY
1	Handle rivet	1	22	Taper pin	4
2	Handle	1	23	Inside cover	1
3	Hexagon bolt	1	24	Roots	2
4	Handle	1	25	Roots shaft(short)	1
5	Oil seal	1	26	Roots shaft(long)	1
6	Stop ring	1	27	Housing	1
7	Bearing	2	28	Outside cover	1
8	Screw(for gear cover)	10	29	Screw(for outside cover)	10
9	Bearing collar	1	30	Bearing cap	2
10	Gear cover	1	31	Spout	1
11	Rhomic bolt	1	32	Hose clamp	1
12	O-ring	1	33	Plastic clip	1
13	Reinforcement shaft	1	34	Delivery hose(PE)	1
14	Reinforcement gear	1	35	Strainer	1
15	Screw(for long Roots shaft)	1	36	L shape	1
16	Pinion gear	1	37	Bung adaptor	1
17	Timing gear	2	38	Filter body	1
18	Taper pin	4	39	Suction pipe	1/2/3
19	Bearing	4	40	Rubber unit	2
20	Oil seal	4	41	Nozzle	1
21	Cover packing	3	42		

TROUBLE SHOOTING

TROUBLE	REMEDY
Handle fails turn	Gears broken-Return for repair. Dirt etc clogging up the pump-Overhaul&clean
Handle is hard to turn	Dirt,ect clogging up the pump-Overhaul&clean. Filter blocked-Clean the filter
Handle turn but no discharge	Gears broken/Shaft or pin broken-Return for repair